


# SPEEDOCAP V3 EVO

Branchement en autonome / Standalone

Wiring / Conexión en autónomo



**MOTO/ BIKE**




4 points



4 points

Câble alim / Power Cable /  
Cable de alimentación GPS Unik4

**CALC-205**



Adaptateur fourni/  
Adapter delivered/  
Adaptator entregado

**SPOC-910**



6 points



6 points



Câble de connexion répéteur/  
Repeater connection cable/  
Cable de conexión del repetidor

**CREP-204 / 206**



3 points



Télécommande/  
Remote control/  
Telemando

**TECO-208**



6 points



6 points

Adaptateur fourni/  
Adapter delivered/  
Adaptator entregado



4 points



The remote allows you to use TRIP + and TRIP -.  
The Menu button is disabled.  
Remember to set the screen at the start of training.

Les adaptateurs joints avec votre Speedocap servent uniquement pour l'utilisation en mode autonome. Attention à bien les conserver.  
The adapters delivered with the Speedocap are needed only for autonomous use. Important: keep them carefully.  
Los adaptadores entregados con el Speedocap solo sirven para la utilización del modo autosuficiente. Cuidado: quedarlos con atención.